



ISMA-4U4A
MODULE

UNIVERSAL INPUTS

U1

U2

G0

U3

U4

G0

ANALOGUE OUTPUTS

A1

A2

G0

A3

A4

G0

Panel

Field